



Only qualified electrical personnel should install this equipment.

Before performing installation or maintenance, disconnect all sources of electric power.
Use appropriate personal protective equipment

(PPE) and follow safe electrical work practices.

Find diagrams for more configurations at wattwatchers.com.au/support

1) Auditor is DIN-rail mounted and requires 35mm wide space.

2) Current transformer installation -For grid monitoring, K is towards grid, arrow is towards load. For solar monitoring, K is towards inverter, arrow is towards load.

3) Current transformers must be suitably secured in position.

4) All wiring shall be tidy and secured in accordance with the wiring rules in your jurisdiction.

5) An existing or new protective device can be used depending on the regulations in your jurisdiction.

6) Follow the rules in your jurisdiction for the use of RCD protection.

Wattwatchers recommends the placement of monitoring CT's on the circuits being switched, but this is not mandatory.

8) For more information, refer to the quick start quide and wattwatchers.com.au/support

| Place current transformer connected to | On cables connected to A-Phase | |
|--|---------------------------------|--|
| Terminals 1+ and 4+ | | |
| Terminals 2+ and 5+ | B-Phase | |
| Terminals 3+ and 6+ | C-Phase | |

| sue | Descr ption | Drawn | Appd | Date |
|-----|-------------|-------|------|-------|
| | Final | 102 | 4 | 93/19 |
| | | | | |
| | | | | |
| | | | | |
| Г | | | | |
| , | | | | |
| | | | | |
| | | | | |
| | | | | |





| | KS | 03/19 |
|---|-------------------|-------|
| Ī | Approved By JC | 03/19 |

| CONNECTION | DIAGRAMS |
|------------|----------|
| | |

| ı | Drawing itle |
|---|---|
| | Drawing itle A6M+3SW MONITORING 3-PHASE MAINS+SOLAR |
| | MONITORING 3-PHASE MAINS+SOLAR |
| | + 3-PHASE LOAD SWITCHING |

| Project Code 20180153 | Status FINAL | Revision |
|--------------------------|-----------------|----------|
| WW018028 | NT S | } |