


Find diagrams for more configurations at wattwatchers.com.au/support

- in your jurisdiction.
- 5) An existing or new protective device can be used depending on the regulations in your jurisdiction.
- Follow the rules in your jurisdiction for the use of RCD protection.
- Wattwatchers recommends the placement of monitoring CT's on the circuits being switched, but this is not mandatory.
- For more information, refer to the quick start guide and wattwatchers.com.au/support

Place current transformer connected to	On cables connected to	
Terminals 1+ and 4+	A-Phase	
Terminals 2+ and 5+	B-Phase	
Terminals 3+ and 6+	C-Phase	







KS KS	03/19
Approved By JC	03/19

Project itle CONNECTION	DIAGRAMS

Drawing itle
A6W+3SW
MONITORING TWO 3-PHASE LOADS
+ 3-PHASE LOAD SWITCHING

Project Code 20180153	Status FINAL	A	
WW018034	NT S	NTS	